

## DMX CONTROL

MODE 4 Ch	FUNCTION	DMX Value
1	<b>RED</b> 0~100%	000 - 255
2	<b>GREEN</b> 0~100%	000 - 255
3	<b>BLUE</b> 0~100%	000 - 255
4	<b>WHITE</b> 0~100%	000 - 255

MODE 6 Ch	FUNCTION	DMX Value
1	<b>DIMMER</b> 0~100%	000 - 255
2	<b>RED</b> 0~100%	000 - 255
3	<b>GREEN</b> 0~100%	000 - 255
4	<b>BLUE</b> 0~100%	000 - 255
5	<b>WHITE</b> 0~100%	000 - 255
6	<b>STROBE</b> No function Strobe Slow to Fast	000 - 010 011 - 255

MODE 10 Ch	FUNCTION	DMX Value
1	<b>DIMMER</b> 0~100%	000 - 255
2	<b>RED</b> 0~100%	000 - 255
3	<b>GREEN</b> 0~100%	000 - 255
4	<b>BLUE</b> 0~100%	000 - 255
5	<b>WHITE</b> 0~100%	000 - 255
6	<b>STROBE</b> No function Strobe Slow to Fast	000 - 010 011 - 255
7	<b>COLOR MACRO + WHITE BALANCE</b> No Function R: 100% / G: 0-100% / B: 0% R: 100-0% / G: 100% / B: 0% R: 0% / G: 100% / B: 0-100% R: 0% / G: 100-0% / B: 100% R: 0-100% / G: 0% / B: 100% R: 100% / G: 0% / B: 100-0% R: 100% / G: 0-100% / B: 0-100% R: 100-0% / G: 100-0% / B: 100% R: 100% / G: 100% / B: 100% / W: 100% White 1 White 2 White 3 White 4 White 5 White 6 White 7 White 8 White 9 White 10 White 11	000 - 010 011 - 030 031 - 050 051 - 070 071 - 090 091 - 110 111 - 130 131 - 150 151 - 170 171 - 200 201 - 205 206 - 210 211 - 215 216 - 220 221 - 225 226 - 230 231 - 235 236 - 240 241 - 245 246 - 250 251 - 255
8	<b>AUTO PROGRAMS</b> No Function Auto program 1 Auto programs 2 Auto programs 3 Auto programs 4 Auto programs 5	000 - 010 011 - 028 029 - 046 047 - 064 065 - 082 083 - 100

MODE 10 Ch	FUNCTION	DMX Value
8	Auto programs 6	101 - 118
	Auto programs 7	119 - 136
	Auto programs 8	137 - 154
	Auto programs 9	155 - 172
	Auto programs 10	173 - 190
	Auto programs 11	191 - 208
	Auto programs 12	209 - 226
	Auto programs 13	227 - 244
	Auto programs 0	245 - 255
9	<b>AUTO SPEED</b> Auto speed slow to fast	000 - 255
10	<b>DIMMER SPEED</b> Preset dimmer speed from display menu	000 - 051
	Dimmer speed mode off	052 - 101
	Dimmer speed mode1 (fast speed)	102 - 152
	Dimmer speed mode2 (middle speed)	153 - 203
	Dimmer speed mode3 (slow speed)	204 - 255

MODE 48 Ch	FUNCTION	DMX Value
1	<b>RED 1</b> 0~100%	000 - 255
2	<b>GREEN 1</b> 0~100%	000 - 255
3	<b>BLUE 1</b> 0~100%	000 - 255
4	<b>WHITE 1</b> 0~100%	000 - 255
5	<b>RED 2</b> 0~100%	000 - 255
6	<b>GREEN 2</b> 0~100%	000 - 255
7	<b>BLUE 2</b> 0~100%	000 - 255
8	<b>WHITE 2</b> 0~100%	000 - 255
9	<b>RED 3</b> 0~100%	000 - 255
10	<b>GREEN 3</b> 0~100%	000 - 255
11	<b>BLUE 3</b> 0~100%	000 - 255
12	<b>WHITE 3</b> 0~100%	000 - 255
...	...	...
...	...	...
...	...	...
16	<b>RED 12</b> 0~100%	000 - 255
17	<b>GREEN 12</b> 0~100%	000 - 255
18	<b>BLUE 12</b> 0~100%	000 - 255
48	<b>WHITE 12</b> 0~100%	000 - 255

MODE 53 Ch	FUNCTION	DMX Value
1	<b>RED 1</b> 0~100%	000 - 255
2	<b>GREEN 1</b> 0~100%	000 - 255
3	<b>BLUE 1</b> 0~100%	000 - 255
4	<b>WHITE 1</b> 0~100%	000 - 255
5	<b>RED 2</b> 0~100%	000 - 255
6	<b>GREEN 2</b> 0~100%	000 - 255
7	<b>BLUE 2</b> 0~100%	000 - 255
8	<b>WHITE 2</b> 0~100%	000 - 255
9	<b>RED 3</b> 0~100%	000 - 255
10	<b>GREEN 3</b> 0~100%	000 - 255
11	<b>BLUE 3</b> 0~100%	000 - 255
12	<b>WHITE 3</b> 0~100%	000 - 255
...	...	...
...	...	...
...	...	...
16	<b>RED 12</b> 0~100%	000 - 255
17	<b>GREEN 12</b> 0~100%	000 - 255
18	<b>BLUE 12</b> 0~100%	000 - 255
48	<b>WHITE 12</b> 0~100%	000 - 255

MODE 53 Ch	FUNCTION	DMX Value
49	<b>AUTO PROGRAMS</b> No Function Auto program 1 Auto programs 2 Auto programs 3 Auto programs 4 Auto programs 5 Auto programs 6 Auto programs 7 Auto programs 8 Auto programs 9 Auto programs 10 Auto programs 11 Auto programs 12 Auto programs 13 Auto programs 0	000 - 010 011 - 028 029 - 046 047 - 064 065 - 082 083 - 100 101 - 118 119 - 136 137 - 154 155 - 172 173 - 190 191 - 208 209 - 226 227 - 244 245 - 255
50	<b>AUTO SPEED</b> Auto speed slow to fast	000 - 255
51	<b>DIMMER</b> 0~100%	000 - 255
52	<b>STROBE</b> No function Strobe Slow to Fast	000 - 010 011 - 255
53	<b>DIMMER SPEED</b> Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode1 (fast speed) Dimmer speed mode2 (middle speed) Dimmer speed mode3 (slow speed)	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255