

## DMX CONTROL

### 1 CHANNEL

MODE 1 Ch	FUNCTION	DMX Value
1	<b>WHITE</b> 0~100%	000 - 255

### 5 CHANNELS

MODE 5 Ch	FUNCTION	DMX Value
1	<b>DIMMER</b> 0~100%	000 - 255
2	<b>RED</b> 0~100%	000 - 255
3	<b>GREEN</b> 0~100%	000 - 255
4	<b>BLUE</b> 0~100%	000 - 255
5	<b>WHITE</b> 0~100%	000 - 255

### 8 CHANNELS

MODE 11 Ch	FUNCTION	DMX Value
1	<b>DIMMER</b> 0~100%	000 - 255
2	<b>RED</b> 0~100%	000 - 255
3	<b>GREEN</b> 0~100%	000 - 255
4	<b>BLUE</b> 0~100%	000 - 255
5	<b>WHITE</b> 0~100%	000 - 255
6	<b>VIRTUAL COLOR</b> No Function Red	000 - 015 016 - 025

6	Deep Orange Light Orange Light Orange Yellow Green Sea Green Aquamarine Cyan Blue Violet Purple Magenta Full RGB White Gradual	026 - 035 036 - 045 046 - 055 056 - 065 071 - 090 066 - 075 076 - 085 086 - 095 096 - 105 106 - 115 116 - 125 126 - 135 136 - 145 146 - 155 156 - 255
7	<b>SHUTTER FUNCTION</b> Normal Shutter Function Strobe effect slow to fast	000 - 005 032 - 255
8	<b>DIMMER FADE</b> 0~100%	000 - 255

### PIXCH

MODE PIXCH	FUNCTION	DMX Value
1	<b>DIMMER</b> 0~100%	000 - 255
2	<b>VIRTUAL COLOR</b> No Function Red Deep Orange Light Orange Light Orange Yellow Green Sea Green Aquamarine Cyan Blue Violet Purple Magenta Full RGB White Gradual	000 - 015 016 - 025 026 - 035 036 - 045 046 - 055 056 - 065 071 - 090 066 - 075 076 - 085 086 - 095 096 - 105 106 - 115 116 - 125 126 - 135 136 - 145 146 - 155 156 - 255
3	<b>SHUTTER FUNCTION</b> Normal Shutter Function Strobe effect slow to fast	000 - 005 032 - 255
4	<b>DIMMER FADE</b> 0~100%	000 - 255

PIXCH

MODE PIXCH	FUNCTION	DMX Value
5	<b>RED 1</b> 0~100%	000 - 255
6	<b>GREEN 1</b> 0~100%	000 - 255
7	<b>BLUE 1</b> 0~100%	000 - 255
8	<b>WHITE 1</b> 0~100%	000 - 255
25	<b>RED 6</b> 0~100%	000 - 255
26	<b>GREEN 6</b> 0~100%	000 - 255
27	<b>BLUE 6</b> 0~100%	000 - 255
28	<b>WHITE 6</b> 0~100%	000 - 255