

CANALI DMX

BAS-8	BAS-16	FUNCTION	DMX Value
9 ch	11 ch		
1	1	PAN Pan Coarse	000 - 255
	2	PAN FINE Pan Fine	000 - 255
2	3	TILT Tilt Coarse	000 - 255
	4	TILT FINE Til Fine	000 - 255
3	5	MOVEMENT SPEED Fastest to slowest	000 - 255
4	6	SHUTTER Shutter closed No function (shutter open) Strobe effect slow to fast No function (shutter open) Pulse-effect in sequences No function (shutter open) Random strobe effect slow to fast No function (shutter open)	000 - 010 011 - 030 031 - 085 086 - 105 106 - 160 161 - 180 181 - 235 236 - 255
5	7	DIMMER Dimmer (close to open)	000 - 255
6	8	COLOR Indexed Open Open+DARK RED DARK RED DARK RED + DARK BLUE DARK BLUE DARK BLUE + YELLOW YELLOW YELLOW + GREEN GREEN GREEN + LIGHT ORANGE LIGHT ORANGE LIGHT ORANGE + MAGENTA MAGENTA MAGENTA + CYAN CYAN CYAN + C.T.O. C.T.O. C.T.O. + JADE JADE JADE + C.T.B C.T.B C.T.B + PINK PINK	000 - 004 005 - 008 009 - 012 013 - 016 017 - 021 022 - 025 026 - 029 030 - 033 034 - 038 039 - 042 043 - 046 047 - 050 051 - 055 056 - 059 060 - 063 064 - 067 068 - 071 072 - 076 077 - 080 081 - 084 085 - 088 089 - 093 094 - 097

BAS-8	BAS-16	FUNCTION	DMX Value
9 ch	11 ch		
6	8	PINK + LIGHT GREEN	098 - 101
		LIGHT GREEN	102 - 105
		LIGHT GREEN + DARK ORANGE	106 - 110
		DARK ORANGE	111 - 114
		DARK ORANGE + UV FILTER	115 - 118
		UV FILTER	119 - 122
		UV FILTER + Open	123 - 127
		Forward Spin	
		Stop do fast	128 - 189
		Stop roation	
		Stop	190 - 193
		Reverse Spin	
		Fast to Stop	194 - 255
7	9	GOBO	
		Index	
		Position 1 (Open)	000 - 002
		Position 2	003 - 005
		Position 3	006 - 008
		Position 4	009 - 011
		Position 5	012 - 014
		Position 6	015 - 017
		Position 7	018 - 020
		Position 8	021 - 023
		Position 9	024 - 026
		Position 10	027 - 029
		Position 11	030 - 032
		Position 12	033 - 035
		Position 13	036 - 038
		Position 14	039 - 041
		Position 15	042 - 044
		Position 16	045 - 047
		Position 17	048 - 050
		Position 18	051 - 053
		Index with Shake	
		Position 2	054 - 063
		Position 3	064 - 073
		Position 4	074 - 083
		Position 5	084 - 093
		Position 6	094 - 103
		Position 7	104 - 113
		Position 8	114 - 123
		Position 9	124 - 133
		Position 10	134 - 143
		Position 11	144 - 153
		Position 12	154 - 163
		Position 13	164 - 173
		Position 14	174 - 183
		Position 15	184 - 193
		Position 16	194 - 203
		Position 17	204 - 213
		Position 18	214 - 223

BAS-8	BAS-16	FUNCTION	DMX Value
9 ch	11 ch		
		Forward Spin Slow to fast Reverse Spin Fast to slow	224 - 239 240 - 255
8	10	PRISM ROT Open Indexing Insertion and positioning from 0-360 degrees Forward Wheel Spin Stop to fastest Reverse Wheel Spin fastest to stop	000 - 005 006 - 191 192 - 223 224 - 255
9	11	CONTROL No function Enable blackout while Pan/Tilt move (Hold 3 Second) Disable blackout while Pan/Tilt move (Hold 3 Second) Enable blackout while color change (Hold 3 Second) Disable blackout while color change (Hold 3 Second) Enable blackout while gobo change (Hold 3 Second) Disable blackout while gobo change (Hold 3 Second) Pan Reset (Hold 3 Second) Tilt Reset (Hold 3 Second) Color Reset (Hold 3 Second) Gobo Reset (Hold 3 Second) No function Prism Reset (Hold 3 Second) No function Reset all (Hold 3 Second) No function	000 - 039 040 - 049 050 - 059 060 - 069 070 - 079 080 - 089 090 - 099 100 - 109 110 - 119 120 - 129 130 - 139 140 - 149 150 - 159 160 - 169 170 - 179 180 - 255