

DMX CHANNEL

BAS 1CH	STD 3 CH	FUNCTION	DMX Value
1	1	DIMMER Dimmer (close to open)	000 - 255
	2	SHUTTER No function (shutter open) Strobe effect slow to fast No function (shutter open) Pulse-effect in sequences No function (shutter open) Random strobe effect slow to fast No function (shutter open)	000 - 010 011 - 082 083 - 093 094 - 163 164 - 174 175 - 244 245 - 255
	3	DIMMER FADE Preset dimmer speed from display menu Dimmer snap to fade	000 - 000 001 - 255