

# DMX CHARTS

Channel	5 Ch	7 Ch	10 Ch	13 Ch	17 Ch
1	RED	DIMMER	DIMMER	RED 1	DIMMER
2	GREEN	RED	RED	GREEN 1	STROBE 1
3	BLUE	GREEN	GREEN	BLUE 1	STROBE 2
4	WHITE	BLUE	BLUE	WHITE 1	STROBE 3
5	DIMMER SPEED MODE	WHITE	WHITE	RED 2	RED 1
6		STROBE	STROBE	GREEN 2	GREEN 1
7		DIMMER SPEED MODE	COLOR MACRO	BLUE 2	BLUE 1
8			EFFECTS	WHITE 2	WHITE 1
9			EFFECTS SPEED	RED 3	RED 2
10			DIMMER SPEED MODE	GREEN 3	GREEN 2
11				BLUE 3	BLUE 2
12				WHITE 3	WHITE 2
13			DIMMER SPEED MODE		RED 3
14					GREEN 3
15					BLUE 3
16					WHITE 3
17			DIMMER SPEED MODE		

MODE							
5CH	7CH	10CH	13CH	17CH	FUNCTION	DMX Value	Default
	1	1		1	<b>DIMMER</b> Lineary from 0% to 100%	000-255	000
1	2	2			<b>RED</b> Lineary from 0% to 100%	000-255	255
2	3	3			<b>GREEN</b> Lineary from 0% to 100%	000-255	255
3	4	4			<b>BLUE</b> Lineary from 0% to 100%	000-255	255
4	5	5			<b>WHITE</b> Lineary from 0% to 100%	000-255	255
	6	6			<b>STROBE</b> No function Strobe Slow to Fast	000 - 010 011 - 255	000
				2	<b>STROBE 1</b> No function Strobe Slow to Fast	000 - 010 011 - 255	000
				3	<b>STROBE 2</b> No function Strobe Slow to Fast	000 - 010 011 - 255	000
				4	<b>STROBE 3</b> No function Strobe Slow to Fast	000 - 010 011 - 255	000
		7			<b>COLOR MACRO</b> No Function R 100%, G 0~100%, B 0 % R 100%~0 %, G 100%, B 0 % R 0 %, G 100%, B 0~100% R 0 %, G 100~0 %, B 100% R 0~100%, G 0 %, B 100% R 100%, G 0 %, B 100~0 % R 100%, G 0~100%, B 0~100% R 100~0 %, G 100~0 %, B 100% R 100%, G 100%, B 100%, W 100% 2800k 3000k 3200k 4000k 5600k 6000k 6500k 7000k 8000k 9000k 10000k	000 - 010 011 - 030 031 - 050 051 - 070 071 - 090 091 - 110 111 - 130 131 - 150 151 - 170 171 - 200 201 - 205 206 - 210 211 - 215 216 - 220 221 - 225 226 - 230 231 - 235 236 - 240 241 - 245 246 - 250 251 - 255	000
		8			<b>EFFECTS</b> No Function Effect 1 Effect 2 Effect 3 Effect4 Effect5 (Effects1- 4) Effect 6 Effect 7 Effect 8 Effect 9 (Effects6- 8)	000-010 011-037 038-064 065-091 092-118 119-145 146-172 173-199 200-226 227-255	000
		9			<b>EFFECTS SPEED</b> Effects speed slow to fast	000-255	000

MODE							
5CH	7CH	10CH	13CH	17CH	FUNCTION	DMX Value	Default
			1	5	<b>RED 1</b> Lineary from 0% to 100%	000-255	255
			2	6	<b>GREEN 1</b> Lineary from 0% to 100%	000-255	255
			3	7	<b>BLUE 1</b> Lineary from 0% to 100%	000-255	255
			4	8	<b>WHITE 1</b> Lineary from 0% to 100%	000-255	255
			5	9	<b>RED 2</b> Lineary from 0% to 100%	000-255	255
			6	10	<b>GREEN 2</b> Lineary from 0% to 100%	000-255	255
			7	11	<b>BLUE 2</b> Lineary from 0% to 100%	000-255	255
			8	12	<b>WHITE 2</b> Lineary from 0% to 100%	000-255	255
			9	13	<b>RED 3</b> Lineary from 0% to 100%	000-255	255
			10	14	<b>GREEN 3</b> Lineary from 0% to 100%	000-255	255
			11	15	<b>BLUE 3</b> Lineary from 0% to 100%	000-255	255
			12	16	<b>WHITE 3</b> Lineary from 0% to 100%	000-255	255
5	7	10	13	17	<b>DIMMER SPEED MODE</b> Preset dimmer speed from display menu Dimmer speed mode AUTO Dimmer speed mode FAST Dimmer speed mode MEDIUM Dimmer speed mode SLOW	000 - 051 052 - 101 102 - 152 153 - 203 204 - 255	000