

DMX CONTROL

5 CHANNELS

MODE 5 Ch	FUNCTION	DMX Value
1	RED 0~100%	000 - 255
2	GREEN 0~100%	000 - 255
3	BLUE 0~100%	000 - 255
4	WHITE 0~100%	000 - 255
5	ZOOM 0~100%	000 - 255

7 CHANNELS

MODE 7 Ch	FUNCTION	DMX Value
1	DIMMER 0~100%	000 - 255
2	RED 0~100%	000 - 255
3	GREEN 0~100%	000 - 255
4	BLUE 0~100%	000 - 255
5	WHITE 0~100%	000 - 255
6	STROBE No Function (shutter open) Slow to fast No Function (shutter open) Random slow to fast No Function (shutter open)	000 - 030 031 - 100 101 - 130 131 - 200 201 - 255
7	ZOOM 0~100%	000 - 255

11 CANALI

MODE 11 Ch	FUNCTION	DMX Value
1	DIMMER 0~100%	000 - 255
2	RED 0~100%	000 - 255
3	GREEN 0~100%	000 - 255
4	BLUE 0~100%	000 - 255
5	WHITE 0~100%	000 - 255
6	STROBE	
	No Function (shutter open)	000 - 030
	Slow to fast	031 - 100
	No Function (shutter open)	101 - 130
	Random slow to fast	131 - 200
	No Function (shutter open)	201 - 255
7	ZOOM 0~100%	000 - 255
8	COLOR FUNCTION	
	No Function	000 - 010
	Color presets	011 - 085
	CTC	086 - 130
	CTC+Amber Shift	131 - 170
	Effects	171 - 255
9	COLOR PRESETS	
	R 100%, G 0~100%, B 0%	000 - 028
	R 100%~0%, G 100%, B 0%	029 - 056
	R 0%, G 100%, B 0~100%	057 - 084
	R 0% G 100%~0% B 100%	085 - 112
	R 0%~100% G 0% B 100%	113 - 140
	R 100% G 0% B 100%~0%	141 - 168
	R 100% G 0%~100% B 0%~100%	169 - 196
	R 100%~0% G 100%~0% B 100%	197 - 224
	R 100% G 100% B 100% W 100%	225 - 255

11 CHANNELS

MODE 11 Ch	FUNCTION	DMX Value
9	CTC Or CTC+Amber Shift	
	2800K	000 - 000
	3000K	001 - 010
	3200K	011 - 020
	3400K	021 - 030
	3600K	031 - 040
	3800K	041 - 050
	4000K	051 - 060
	4200K	061 - 070
	4400K	071 - 080
	4600K	081 - 090
	4800K	091 - 100
	5000K	101 - 110
	5200K	111 - 120
	5400K	121 - 130
	5600K	131 - 140
	5800K	141 - 150
	6000K	151 - 160
	6200K	161 - 170
	6400K	171 - 180
	6600K	181 - 190
	6800K	191 - 200
	7000K	201 - 210
	7200K	211 - 220
	7400K	221 - 230
	7600K	231 - 240
	7800K	241 - 250
	8000K	251 - 255
10	EFFECTS	
	Effects 1	000 - 060
	Effects 2	061 - 110
	Effects 3	111 - 160
	Effects 4	161 - 210
	Effects 5 (Effects 1- 4)	211 - 255
	EFFECTS SPEED	
	Effects speed slow to fast	000 - 255
	HUE	
	0	000
	-25~25 (Ch8. is 86-130 and 131-170)	001 - 255
11	DIMMER FADE Preset dimmer speed from display menu 0~100%	000 - 000 001 - 255

22 CANALI

MODE 22 Ch	FUNCTION	DMX Value
1	DIMMER 0~100%	000 - 255
2	DIMMER Fine 0~100%	000 - 255
3	STROBE No Function (shutter open) Slow to fast No Function (shutter open) Random slow to fast No Function (shutter open)	000 - 030 031 - 100 101 - 130 131 - 200 201 - 255
4	WHITE FUNCTION CTC CTC+Amber Shift	000 - 127 128 - 255
5	CTC or CTC+Amber Shift 2800K 3000K 3200K 3400K 3600K 3800K 4000K 4200K 4400K 4600K 4800K 5000K 5200K 5400K 5600K 5800K 6000K 6200K 6400K 6600K 6800K 7000K 7200K 7400K 7600K 7800K 8000K	000 - 000 001 - 010 011 - 020 021 - 030 031 - 040 041 - 050 051 - 060 061 - 070 071 - 080 081 - 090 091 - 100 101 - 110 111 - 120 121 - 130 131 - 140 141 - 150 151 - 160 161 - 170 171 - 180 181 - 190 191 - 200 201 - 210 211 - 220 221 - 230 231 - 240 241 - 250 251 - 255
6	HUE -25 0 +25	000 - 127 128 - 128 129 - 255
7	CROSSFADE 0~100%	000 - 255

22 CANALI

MODE 22 Ch	FUNCTION	DMX Value
8	RED 0~100%	000 - 255
9	RED Fine 0~100%	000 - 255
10	GREEN 0~100%	000 - 255
11	GREEN Fine 0~100%	000 - 255
12	BLUE 0~100%	000 - 255
13	BLUE Fine 0~100%	000 - 255
14	WHITE 0~100%	000 - 255
15	WHITE Fine 0~100%	000 - 255
16	COLOR FUNCTION No function Color presets Effects	000 - 085 086 - 171 172 - 255
17	COLOR PRESETS R 100%, G 0~100%, B 0% R 100%~0%, G 100%, B 0% R 0%, G 100%, B 0~100% R 0% G 100%~0% B 100% R 0%~100% G 0% B 100% R 100% G 0% B 100%~0% R 100% G 0%~100% B 0%~100% R 100%~0% G 100%~0% B 100% R 100% G 100% B 100% W 100%	000 - 028 029 - 056 057 - 084 085 - 112 113 - 140 141 - 168 169 - 196 197 - 224 225 - 255
	EFFECTS Effects 1 Effects 2 Effects 3 Effects 4 Effects 5 (Effects1- 4)	000 - 060 061 - 110 111 - 160 161 - 210 211 - 255
18	EFFECTS SPEED Effects speed slow to fast	000-255
19	CTO ON COLORS 0~100%	000 - 255
20	ZOOM 0~100%	000 - 255
21	ZOOM Fine 0~100%	000 - 255
22	DIMMER FADE Preset dimmer speed from display menu 0~100%	000 - 000 001 - 255