




DMX CONTROL

CHANNEL			FUNCTION	DMX Value
8CH	15CH	18CH		
1	1	1	LED STRIP SHUTTER Shutter closed Strobe effect slow to fast No function (shutter open) Pulse-effect in sequences No function (shutter open) Random strobe effect slow to fast No function (shutter open)	000 - 010 011 - 082 083 - 093 094 - 163 164 - 174 175 - 244 245 - 255
2	2	2	LED STRIP DIMMER Dimmer 0% ~ 100%	000 - 255
	3	3	LED STRIP DIMMER FADE OUT 0% to 100%	000 - 255
3	4	4	LED STRIP VIRTUAL COLOR FUNCTION On Function White presets Function Forward Spin Reverse Spin Continuous Color Bounce TBD	000 - 015 016 - 031 032 - 047 048 - 063 064 - 079 080 - 111 112 - 255
4	5	5	LED STRIP VIRTUAL COLOR1 White presets Function White 2000K ~ 2700K White 2700K ~ 3200K White 3200K ~ 4200K White 4200K ~ 5600K White 5600K ~ 8000K White 8000K ~ 10000K Forward Spin Rainbow Effect (Slow->Fast) Reverse Spin Rainbow Effect (Slow->Fast) Continuous & Color Bounce Black Red Green Blue White Red=0, Green->up,Blue=full,White=0 Red=0, Green=full,Blue->down,White=0 Red->up, Green=full,Blue=0,White=0 Red=full, Green->down,Blue=0,White=0 Red=full, Green=0,Blue->up,White=0 Red->down, Green=0,Blue=full,White=0	000 - 042 043 - 085 086 - 128 129 - 171 172 - 214 215 - 255 000 - 255 000 - 255 000 001 002 003 004 005 - 046 047 - 088 089 - 130 131 - 172 173 - 214 215 - 255

CHANNEL			FUNCTION	DMX Value
8CH	15CH	18CH		
5	6	6	LED STRIP VIRTUAL COLOR2 (Only On Color Bounce) Black Red Green Blue White Red=0, Green->up,Blue=full,White=0 Red=0, Green=full,Blue->down,White=0 Red->up, Green=full,Blue=0,White=0 Red=full, Green->down,Blue=0,White=0 Red=full, Green=0,Blue->up,White=0 Red->down, Green=0,Blue=full,White=0	000 001 002 003 004 005 - 046 047 - 088 089 - 130 131 - 172 173 - 214 215 - 255
6		7	LED STRIP RED 0~100% 	000 - 255
7		8	LED STRIP GREEN 0~100% 	000 - 255
8		9	LED STRIP BLUE 0~100% 	000 - 255
	7	10	LED STRIP PATTERN On Pattern Pattern control Pattern Effect Random Pattern Effect	000 - 015 016 - 031 032 - 176 177 - 255
	8	11	LED STRIP PATTERN SPEED Pattern control Picture Effect 1-250 Pattern Effect & Random Pattern Effect Static indexing Forward Slow to fastest Stop Reverse Slow to fastest	000 - 255 000 - 023 024 - 137 138 - 141 142 - 255
	9	12	LED STRIP DIMMER TRANSITION Dimmer 0% ~ 100%	000 - 255
	10	13	LED STRIP FOREGROUND No Function Foreground Color	000 - 003 004 - 255
	11	14	LED STRIP FOREGROUND DIMMER Dimmer 0% ~ 100%	000 - 255
	12	15	LED STRIP FOREGROUND SHUTTER Shutter closed Strobe effect slow to fast No function (shutter open) Random strobe effect slow to fast No function (shutter open)	000 - 010 011 - 163 164 - 174 175 - 244 245 - 255

SMARTOWER - SMARTOWERPACK

CHANNEL			FUNCTION	DMX Value
8CH	15CH	18CH		
	13	16	LED STRIP BACKGROUND No Function Foreground Color	000 - 003 004 - 255
	14	17	LED STRIP BACKGROUND DIMMER Dimmer 0% ~ 100%	000 - 255
	15	18	LED STRIP BACKGROUND SHUTTER Shutter closed Strobe effect slow to fast No function (shutter open) Random strobe effect slow to fast No function (shutter open)	000 - 010 011 - 163 164 - 174 175 - 244 245 - 255