

ECL PROFILE series

Mounting ETC optics



Update Purpose: Mounting ETC zoom optics or ETC middle part on Ecl HD series

Tools and parts required: PH2 screw driver, M13 wrench, spare part code: **5000000015**

Contacts: support@musiclights.it


Contact your Area Sales Manager for parts orders and delivery

Ecl HD series (EclHD, EclFC, EclHD2)

1) Remove the middle part of the fixture




2) Unscrew nut and hand knob from both sides of the fixture to remove bracket





3) Unscrew the noted screws to remove the metal plate from both sides of the fixture



4) Unscrews the noted screws to remove the noted holders from both sides of the fixture



5) Replace the parts with spare code: **5000000015** on both sides of the fixture and remount it back



New part is shorter on one side

ECL PROFILE series

Mounting ETC optics



Update Purpose: Mounting ETC zoom optics or ETC middle part on Ecl FWseries

Tools and parts required: PH2 screw driver, M5 hex key, product code: **ECLLZLLKA**

Contacts: support@musiclights.it

Contact your Area Sales Manager for parts orders and delivery

Ecl FW series (EclFS, EclFW, Ecl CTPlus)

- 1) Remove the screw from the bottom part of the fixture to remove the middle part



- 2) Replace it with product code: **ECLLZLLKA**

