

CANALI DMX

BAS-3C 3 C	STD 9C	EXT 21C	FUNCTION	DMX Value
	1		Red 0~100%	000 - 255
	2		Green 0~100%	000 - 255
	3		Blue 0~100%	000 - 255
	4		White 0~100%	000 - 255
1	5	1	DIMMER 0~100%	000 - 255
	6	2	Strobe Open Strobe slow to fast Open Random slow to fast Open	000 - 015 016 - 115 116 - 135 136 - 235 236 - 255
2	7	3	Macro No function Flame 1 Flame 2 Flame 3 Flame 4 Program1 (Bounce) Program2 (From top) Program3 (From bottom) Random dimmer	000 - 010 011 - 040 041 - 070 071 - 100 101 - 130 131 - 160 161 - 190 191 - 220 221 - 255
3	8	4	Macro speed Slow to fast	000 - 255
	9	5	Dimmer fade Preset dimmer speed from display menu Dimmer snap to fade	000 - 000 001 - 255
			Pixel 1	
		6	Red 0~100%	000 - 255
		7	Green 0~100%	000 - 255
		8	Blue 0~100%	000 - 255
		9	White 0~100%	000 - 255
			Pixel 2	
		10	Red 0~100%	000 - 255
		11	Green 0~100%	000 - 255
		12	Blue 0~100%	000 - 255
		13	White 0~100%	000 - 255

BAS-3C 3 C	STD 9C	EXT 21C	FUNCTION	DMX Value
			Pixel 3	
		14	Red 0~100%	000 - 255
		15	Green 0~100%	000 - 255
		16	Blue 0~100%	000 - 255
		17	White 0~100%	000 - 255
			Pixel 4	
		18	Red 0~100%	000 - 255
		19	Green 0~100%	000 - 255
		20	Blue 0~100%	000 - 255
		21	White 0~100%	000 - 255