


APIX series

LED DISPLAY



USER MANUAL

This manual is only for operating instructions and does not serve as repairing service.

Changes

The user is cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This manual is provided 'as is' without warranty of any kind, either expressed or implied, including but not limited to the implied warranties or merchantability and fitness for a particular purpose. Improvements and/or changes to the product(s) and/or the program(s) described in this publication at any time without notice.

This publication could contain technical inaccuracies or typographical errors. Changes are periodically made to the information in this publication; these changes are incorporated in new editions of this publication.

Regulatory

The product has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the product is operated in a commercial environment. The product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of the product in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at the user's own expense.

Copyright

All rights reserved. The copyright of this manual is protected by the Copyright Law and other intellectual property laws. No part of this document may be copied, reproduced, distributed, translated, or used for commercial purposes. It shall not otherwise be recorded, transmitted or stored in a retrieval system without the prior written consent.

Contents

1. Safety	1
2. Installation Requirements	3
2.1 Mechanical Requirements.....	3
2.2 Electrical Requirements.....	4
2.3 System Requirements.....	5
3. System Introduction	6
3.1 Brief Introduction.....	6
3.2 System Components.....	6
3.3 LED Display Components.....	8
3.4 LED Control System.....	12
3.5 LED System Control Software.....	15
3.6 Peripheral Device.....	16
3.7 Power Distribution System.....	19
4. Setup Process	21
4.1 Installation Preparation.....	21
4.2 Setup Process of Suspended Installation	23
4.3 Setup Process of Standing Installation.....	26
4.4 Data and power Cabling.....	33
5. Start-up of the System	30
5.1 Software installation.....	30
5.2 System Operation.....	30
6. Trouble Shooting	34
6.1 Software Trouble.....	34
6.2 Hardware Trouble.....	35
6.3 Module Problems.....	36
6.4 Power Problems.....	36
6.5 Data Transfer Problems.....	36
7. Maintenance	37
Appendix A. Technical Specification	38
Appendix B. Tile Dimensions	39

1. SAFETY

This chapter contains important information to prevent personal injury and product damage when you install the display. Read this chapter and keep it properly. Ensure that you understand and follow all the safety instructions and warnings in this chapter before installing.

Personal Protection

	Warning: Ensure that you understand and follow all the safety instructions, warnings mentioned in this manual.
	Warning: Pay attention to electric shock.
	Warning: Wear a hard hat to reduce the risk of personal injury.
	Warning: Be aware of suspended loads.
	Warning: Mind your fingers while dealing with heavy loads.

Personnel of installation and maintenance

The installation and maintenance of this product must be performed by authorized and qualified technical personnel only. The manufacture dose not take responsibility for the results caused by incorrect, improper, irresponsible and unsafe actions.

GND and Lightning protection

Do not underestimate the safety protection of grounding plug/socket. If the supplied plug/socket is defective, replace the defective parts. Ground the product correctly to avoid electric shock caused by large electricity leakage.

Disconnect the power in the time of lightning, or provide other suitable lightning protection device. Disconnect the power plug when the product is not used in a long period.

Ambience of installation and use

- The ambient temperature for LED display: max 50°C, min -20°C.
- Ensure that the ventilation is good. Do not jam or drop metal particles and cable pieces into ventilation opening. Keep the ventilation surface clear without foreign matters like wrapping materials. False actions may lead to poor ventilation and cause fire, malfunction and error.
- Install LED display far away from radiator, heater, furnace and other equipments hindering ventilation and heat dissipation (including but not limited to amplifier, laser, ultrasonic vibration devices), flammable materials (like curtains) and other unsafe devices.
- I/O signal cables should be shielded to restrain the high-frequency interference.
- LED display can not contact with any corrosive and abrasive matter. Do not use LED display in moist ambience, in ambience containing airborne contaminant, dust, oily fume, corrosive gas and flammable gas, and in ambience with vibration and shock.
- This LED indoor product is designed only for indoor use. Never install and use it in outdoor environment and keep it far away from direct sunlight, dust and moisture.

APIX series

ESD and LED:

LED components are ESD (Electro-static Discharge) sensitive. Do not touch LED components when the display is in operation or switched off.

Disconnect device:

When the appliance inlets of the individual tiles are not accessible, the socket outlets supplying the rack shall be installed near the equipment and be easily accessible, or a readily accessible general disconnect device shall be incorporated in the fixed wiring.

Mounting parts:

The mounting parts are only used to install LED display. Do not repair or copy. Only use parts appointed by the manufacturer.

Product care:

Inspect all installations on a routine basis to check security, wear, deformation, corrosion or any other situation that reduces load-carrying capability. Increase inspection frequency for key parts. Keep structural and mounting parts dry, clean, lubricated (only if recommended), coated properly, and maintain complying with part design. Defective parts must be removed or replaced at once.

Installation and wiring:

Install the display and connect cables following the manual instructions. The installation and wiring must be secure. Poor connection may lead to malfunction. Do not step on power/data cable or squeeze plug, socket and power/data cable. Do not suspend any items on cables or the back of LED display. Connect or disconnect the cables of data communication, extension module or control unit after the power is off to prevent product damage or malfunction.

Risk of electric shock:

- To avoid electric shock and damage , do not dismantle the inside electrical parts.
- Do not hot plugging the cables to prevent electric shock or circuit damage.
- Keep clean after installing and cabling. Be ensure all the devices and terminals are covered before tune on the power.
- Do not touch the terminals when power is on. Clean and screw the terminals when power is off.

Moving or transporting product:

Do not hit the corners of LED tiles when installing or dismantling LED tiles. Be careful when moving or transporting the product to prevent any damage.

LED tiles can not be transported in original flight cases or packaging. Even the use of packaging does not guarantee the LED tiles against damage due to excessive force of impacts. All warranty claims regarding damaged modules due to incorrect packing will be rendered invalid.

2. INSTALLATION REQUIREMENTS

This chapter specifies the requirements for safety, mechanism, electricity and control software of APIX series LED display.



Warning: This LED indoor product is designed only for indoor use. Never install and use it in outdoor environment and keep it far away from direct sunlight, dust and moisture.

2.1 Mechanical Requirements

Weight



Warning: Do not underestimate the weight of a complete APIX series LED display. Be sure that The floor or truss installation on which the APIX series display has to be installed is capable of Handling five (5) times the complete load of the display. For floor mounting, conclude the weight of any other load.

Caution: One APIX series tile weighs approximately 8 kg (Outdoor product is 9 kg).

Horizontal surface

For floor installation, the floor on which APIX series display is installed must be horizontal. Never install LED display on a slant surface.

Ballast

Depending on the height of the display and the position of the LED display upon the foot beams (somewhere between front and middle) , additional weight (ballast) will be required. Consult professionals to calculate the minimum ballast you require for safe installation of he LED display.

Truss beam

The truss beam has to be provided and installed by the customer. Pay attention to following points for installation design and preparation. Calculate precisely for on individual basis.

Weight tolerances: Ensure that the truss beam and the ceiling against which the truss beam has to be installed is able to handle the complete weight of the APIX series LED display.

Ceiling stability.

Installation ambience

Environmental conditions: humidity, ventilation, temperature, etc.

Location: Altitude, etc.

Front clearances: for optimal effect, ensure that enough free space is supplied in front of the LED display and respect the minimum viewing distance.

Comply with local regulations regarding such installations.

Warning: Suspending installation is limited to 20 tiles in vertical direction.



2.2 Electrical Requirements

Power requirements

The displaying area of one APIX series tile is 0.250 m². APIX series LED tiles have different pixel densities (see Appendix A – technical specifications). For different pixel densities, one APIX series tile may need power supply of 0.6 amps to 1.5 amps at 220 VAC, 100-250 VAC, 50-60 Hz. Each APIX series tile has one input and one output socket of AC power. The power is distributed to display tiles by power split cables from power distributor. However, one power split cable can be connected with 8 – 20 tiles in parallel. So, one power split cable has to be provided for every 8 – 20 tiles.

Protect every power cable by a circuit breaker or fuses rated 16 A / 250 VAC (15 A / 110 VAC in the USA and Canada). We provides a range of power distributor to satisfy the demands of your LED display. See more details for power distributor of LED display in Power Distribution Section. Contact for more information.

Power system

It is recommended to use power distribution system with a separate neutral and grounding conductor to avoid large current loops due to voltage differences in the neutral conductor.

- Protect the electrical installation by switch, circuit breaker, over-voltage protector, defective-grounding circuit breaker with proper rated power.

- Install the display in accordance with local electrical installation standards. In Europe, comply with EN 60364, the standard for electrical installation of buildings. In Germany, comply with EN 60364. In America, comply with National Electrical Code ANSI/NFPA 70.

Protective grounding

To prevent against the risk of electric shock, the installation should be properly grounded. Defeating the purpose of grounding will expose you to the risk of electric shock.

2.3 System Requirements

Before you begin, it is assumed that you are familiar with the Windows operating software. The CD-ROM in your package contains a Windows 7-based installation program. You can install the software from the CD-ROM.

System requirements

Minimum specifications:

- Hardware
 - PC Pentium IV 2.0 GHz or equivalent
 - 1 GB RAM
 - Free hard disk space: 10GB
 - XGA resolution (1024 x 768)
 - Serial communication port
 - Ethernet connection
- Software
 - Windows 7 Professional

Recommended specifications:

- Hardware
 - PC Intel i5 processor or above
 - 4GB RAM
 - Free hard disk space: APIX series GB
 - SXGA resolution (1280 x 1024), with 512MB video memory
 - Serial communication port
 - Ethernet connection
- Software
 - Windows 7 Professional

3. SYSTEM INTRODUCTION

3.1 Brief Introduction

APIX series is the LED indoor display that uses die-casting aluminum frame with CNC high precision machining techniques. With its compact, light and handy exterior, the LED tile is easy to install and disassemble. As the tile dimension is of very high precision, so the whole display keeps in high flatness and seamless.

3.1.1 Key Benefits

- High resolution and high pixel density, reproducing reality of high definition video
- Uniform color and high contrast, ensuring clear and sharp picture
- High precision die-casting aluminum tile, achieving high flatness and seamless matching of the whole display
- Fan-less design with good heat dissipation, achieving noise-free
- Light and slim tile, easier to handle and transport
- High stability and reliability, prolonging lifespan of the display

3.1.2 Applications

Indoor hall, multi-functional conference hall, performing hall, theater, stage, command and control center and so on.

Outdoor product can be used in outdoor stage and other outdoor environment.

3.2 System Components

APIX series LED display system includes the following basic components:

LED Display: APIX series LED display tiles, power supply cables, signal cables, connectors

•**Control System:** control computer, LED display controller, DVI splitter, control system software

•**Power Distribution System:** power distribution box, power cables

•**Peripheral Devices:** video processor, optical fiber transmitter

APIX series

LED Display Components List

Number	Name	Function /Explanation
LED Display Components		
1	APIX series display tile	Tile size: 500mm X 500mm, Weight: 8 kg
2	Power cord plug and socket	Used for power cable loop connection between tiles; plug for input and socket for output
3	RJ45 data cord plug and socket	Used for data link between tiles; both sockets can be used for output or input
Control System Components		
1	LED display control computer	Industrial control computer
2	Controller (sending card)	Configure and send video signal
3	Graphic card	Support the output of multiple screens
4	Light sensor	Adjust brightness automatically according to environment brightness
5	Receiver card	Receive signal data (One card for one tile)
6	Multi-Function card	Support power supply remote control, support feeding back humidity and temperature information.
7	LED control system software	1.Control, configure and publish play list on LED display 2.Support calibration on-site 3.Support manual and automatic brightness adjustment 4.Support turning on/off LED display through remote network
Power Distribution System Components		
1	Main power distributor	Supply power for LED screen (Support power supply remote control)
2	Power distribution box	Support power supply remote control
3	Lightning arrester	International brand, to avoid lightning
4	Power cable	Comply with international standards
Peripheral Devices		
1	Video processor	Support for peripheral video source
2	Optical fiber transmitter	Both single mode and multiple modes optical fiber transmitter can be used; multiple modes transmitter for APIX M, and single mode transmitter for 20KM
3	Optical fiber	8 cores optical fiber with premium brand
4	Heat sink devices	Axial flow fan can be chosen according to the heat dissipation space and the environment temperature



Warning: LED display modules can be easily damaged, so the original packing materials needed for the maintenance of modules. All the warranty claims are invalid for the damage caused by wrong package.

3.3 LED Display Components

APIX series Tile

APIX series LED display is built with APIX series tiles. A tile consists of die-casting aluminum frames in high accuracy, APIX series display modules, switching power supply, receiver cards, and some other mechanical and electrical connection parts. The APIX series die-casting aluminum frame adopts one time die-casting and CNC precision processing technology with high quality aluminum to ensure the high accuracy of the frame and the uniformity of the whole display.

The introduction of the main components of APIX series tile is shown as below with related images.

3.3.1 Die-Casting Aluminum Frame

Each die-casting aluminum frame is installed with four APIX series display modules. There are LED signal receiver cards and low voltage DC switching power supply inside the frame, and they all have electrical connection with 4 modules. There are special designs for fixing and connecting the tiles at each side of the die-casting aluminum frame. The frame has attachment points at the back and four corners. The attachment points are to fix the tiles to the supports like steel structures and buildings.




Image 3-1 The front face of APIX series display tile

APIX series

APIX series tile has 4 grids for 4 modules to be fixed in. Each grid has 8 magnets/ screw holes to fix one module. The precise positioning ensures the precise positioning of all modules. Keep magnets clean to achieve smooth installation of the modules and avoid seams between tiles and uneven pixel pitches.

Each of the four corners at the back of APIX series die-casting aluminum frame has a fixed screw hole to support the installation. Each side of the upper frame has fast locks used for the precise connection between the upper and lower tiles.



Warning: A maximum of 20 tiles are limited to stack up or suspend without the external support.




Image 3-2 The back face of APIX series display tile

APIX series

3.3.2 APIX series Module

APIX series module includes plastic cover, PCBA, plastic mask, etc. At the back of the plastic base frame, Both front and back service design. Over the lamps, replaceable masks are equipped to protect the LED lamps and PCB and increase the use life of display. The best color SMD LED lamps are provided as materials. Which lead to high uniformity and perfect show effect .The use of black organic silicone makes the black LED lamps darker to improve the contrast of the display significantly.

APIX series tile includes 2×2 modules. Each module has five kinds of pixel pitch (mm): PH 3.91 mm & PH 4.81 mm with the corresponding module resolution (pixel) of 64×64 & 52×52. The weight of each display module is about 1kg.



Warning: APIX series die-casting aluminum frame can only install APIX series display modules.




Image 3-3 The components of APIX series display module

APIX series

3.3.3 Socket and Plug for Power and Data Connection

The following two types of socket and plug are respectively used for the power and data connection between APIX series display tiles. Both data and power socket is for the data or power connection between upper and lower tiles.



Image 3-4 Data and power plug and socket




Image 3-5 Data and power plug and socket

3.3.4 LED Receiver Card

Each APIX series tile has one receiver card for receiving and transmitting the data of LED display . The functions of the MRV300 receiver card are shown as below:

- Power supply: 3.3 - 5.0V
- Temperature monitoring (standard feature)
- Power supply voltage monitoring (standard feature)
- Working status monitoring (standard feature)
- 16 RGB data groups output (it can be extended to 32 groups.)
- Load capacity of single receiver card up to 256×208
- Support pixel level brightness/color calibration




Image 3-6 MRV220 receiver card

APIX series

3.4 LED Control System

This chapter introduces the control system and software of APIX series display.

3.4.1 MCTRL300 Controller

MCTRL300 is LED controller with autonomous power supply. The main functions are shown as below:

- 1.DVI interface for video input
- 2.USB interface for instruction communication
- 3.Resolutions supported: 1024×1200,1280×1024,1600×848,1920×712,2048×668
- 4.Two serial interfaces
- 5.Light sensor interface integrated
- 6.Audio input interface integrated



Image 3-7 MCTRL300 controller

APIX series

3.4.2 MSD300 Transmitter Card

- 1.DVI interface for video input
- 2.USB interface for instruction communication
- 3.Audio input interface
- 4.Resolutions supported:1024*1200, 1280*1024, 1600*848, 1920*712, 2048*640



Caution: A multifunction card is required for audio output.



Image 3-8 MSD300 sending card

3.4.3 MCTRLR Controller

- 1.Two DVI interfaces for cascade (video input and output)
- 2.Audio input interface
- 3.Optional data output interfaces (4 RJ45 Ethernet ports or 4 optical fiber ports) to scan boards (receiver cards)
- 4.RS232 serial ports for cascading instruction communication
- 5.Maximum load capacity: 1920×1200



Image 3-9 MCTRLR controller

APIX series

3.4.4 MFN300 Multifunction Card

- 1.RJ45 ports for connection with receiver cards
- 2.serial ports for connection with the control computer
- 3.Support 8 power supply control
- 4.Support light sensors
- 5.Support temperature and humidity monitoring
- 6.Audio input interface



Caution: The best connect position of function card should be between sending card and the first receiving card , either terminal or socket can be chosen for DC input.




Image 3-10 MFN300 multi-function card

3.4.5 NS048C Light Sensor

- 1.For environment brightness monitoring
 - 2.Connect to controllers(MSD300, MCTRL300) or multifunction cards (MFN300)
- The cable of standard configuration is 5 meters. With a special ordered cable, the working distance can be extended up to 100 meters.



Image 3-11 NS048C light sensor



Note: Consult the controller manual for more information about installation and usage guidelines.

APIX series

3.5 LED System Control Software

NovaLCT-Mars control software is used to configure and control LED display through PC. Software interface as follow :




Image 3-12 NovaLCT-Mars control software interface



Note: For more information about installation and instruction of control software, consult *Nova LED Display Control System –Mars 3 User Manual*.

3.6 Peripheral Device

M3 CVT310/CVT320 (EO converter)

When the distance between LED display and the controller is beyond 100 meters, optical converter is needed to ensure the stable signal transmit and high quality. There are two complete solutions of optical fiber transmission including transmitter, receiver and optical fiber. Your choice depends on the required cable length.

Main Features:

- Use optical fiber of multimode, double cores and LC interface. Transmission distance up to 300m.
- One RJ45 Ethernet port for data input
- Power supply: 100 - 240V AC
- Use in pair.



Image 3-13 LC-LC fiber cable




Image 3-14 CVT 310 transmitter, receiver and optical fiber



Note: Consult control system manual for more information about installation and usage guidelines.

APIX series

Video Processor




Image 3-15 Video processor front view

Menu Key Functions			
PIP	Picture in picture function key	1/AV1	Numerical1/select AV1
CROP	Picture cropping key	2/AV2	Numerical2/select AV2
PART	Partial/Full display switch	3/AV3	Numerical3/select AV3
OK	Confirmation key	4/AV4	Numerical4/select AV4
AUTO	Automatic pixel location alignment key	5/FADE	Numerical5/fading transition
MODE	Preset mode call-out	6/VGA1	Numerical6/select VGA1
MENU	Main menu key, or up to previous key	7/VGA2	Numerical7/selectVGA2
LEFT	Moving cursor to left	8/DVI	Numerical8/select DVI
UP	Moving cursor to top	9/HDMI	Numerical9/select HDMI
DOWM	Moving cursor to bottom	10/E.M.	Numerical10
RIGHT	Moving cursor to right		





Image 3-16 Video processor rear side


Video Inputs		Video Outputs	
AV1~AV4	4 video inputs	DVI1~DVI2	2 DVI outputs (DVI-D single link)
VGA1~VGA2	2 VGA inputs	VGA	1 VGA output
DVI	1DVI input (DVI-D single link)	DVI Loop	1DVI loop output
HDMI	1 HDMI input	Tx Board1/ Tx Board2	Slots for 2 Tx Boards
E.M.	Extension module		

APIX series



Video processor with one transmitter card

Transmitter card seated



Video processor with two transmitter cards

Transmitter cards seated

Image 3-17 Video processor with sending card installed

3.7 Power Distribution System

Power Distribution Tile

The use of proper AC distribution system is necessary to make sure the safe operation to APIX series LED display. Although the third party solution is available, There are power distribution solutions with various sizes and types. As for the small system, “single-phase power box” can be used, while for the medium system, each of the customized power boxes solutions can be used.



Image 3-18 Single-phase power box



Image 3-19 Three-phase power cabinet



Note: Consult the power box manual for more information about installation and usage guidelines.

Power Supply Location

Install power distribution cabinet in the control room outside of the display structure. Install a control box inside the display structure, which can control the display power supply independently, and control the maintenance of sockets and the lighting equipment. If it is 3-phase power supply, each phase should bear equally.

Power Distribution System

The power distribution cabinet has air switch, leakage protection switch, fuses, AC contactors, power lightning arrester. The door of the cabinet is also equipped with current-voltage testing meters, knob switches and signal lights. The distribution cabinet has protection of lightning, over voltage, over current, under voltage, short circuit, open circuit and leakage. The main switches in the power distribution cabinet are made of the Schneider devices and all other accessories and wires has "CCC" certification.




Image 3-20 Typical power supply system diagram

Selecting and layout of the power line

- LED display is supplied with AC220V power with good grounding and requires that the grid voltage fluctuation is less than 10%.
- Determine the diameter of the power cord according to the power of the display (Unit: mm², the cross-sectional area of the power cord).
- Power lines: set aside 5-10m between the power distribution box and the display. Cable: set aside 5-10m between the control room and the display.

The power supply has three-wire system (live, neutral and earth) or five-wire system (3 live wires, neutral and earth). When the maximum power consumption of the LED large-display is less than 10 KW, generally use single-phase three-wire power supply , and vice versa use the three-phase five-wire power supply.

4. SETUP PROCESS

This chapter describes the process of suspended installation and standing installation of APIX series LED display.



Warning: Safety first. Fence off the installation area before starting to install. Ensure you read, understand and follow the safety instructions mentioned in the chapter “Safety” of this installation manual. Furthermore, make sure that all the installation requirements are fulfilled.

The truss beam and level system used in this chapter are pure instructive, and assumes the truss beam and level system have been installed and answers to the flatness requirements. The customer is free to install his own truss beam and level system according to his own wishes but answering to the mechanical requirements mentioned in this installation manual.

4.1 Installation Preparation

Package Check

- Product Item Number —— Confirmed
- Package —— Perfect
- Complete Screen Appearance —— No Scrape

Cabinet Off-line Test

APIX series cabinet supports off-line test. Users can test each APIX series cabinet without connecting with LED control system. The test steps are as below:

- 1.Make sure that each cabinet is connected directly to power supply.
- 2.Switch on the power.
- 3.Press the test button on the back cover. Each click can change to a new test pattern, several test patterns can be offered such like single color test (white/Red/Green/Blue), scanning test etc.




Image 4-1 Off-line Test button on Cabinet

APIX series

Installation Preparation

Good viewing angle and good sight for the surroundings

- Favorable ventilation conditions
- Safe and stable rating input voltage
- Suitable size, firm and stable installation table-board
- Rear maintenance access is at least 800mm.

Tools list for installation (choice depends on the practical jobsite)

<p>1. Diagonal cutting pliers</p>  <p>Cut the wire</p>	<p>2. Combination pliers</p>  <p>Cut the steel wire rope</p>	<p>3. Screw drivers</p>  <p>Install tiles and power supply</p>
<p>4. L shape spanners</p>  <p>Tighten or loosen the screw</p>	<p>5. End wrench tool set</p>  <p>Tighten or loosen the screw</p>	<p>6. Adjustable wrench</p>  <p>Install tiles</p>
<p>7. Socket wrench</p>  <p>Assemble the screen</p>	<p>8. Digital multi-meter</p>  <p>Measure voltage or current</p>	<p>9. Rubber hammer</p>  <p>Adjust the gap between tiles</p>

Other tools for installation (choice depends on the practical jobsite)

Tools	Quantity	Function
Electric drill	1pc	Drill holes on the wall or frame
Rivet drill	1pc	Fix the cabinet in place
Electric adhesive plaster	Several	Isolate electricity after wire connected
Tape measure	1pc	
High-brightness flashlight	1pc	Used in the dark area
Safety rope	Ref.	Personal safety, very important
220V power outlet board	1pc	Power supply
Level & vertical ruler	1pc	Test the level of the frame

APIX series

4.2 Setup Process of Suspended Installation



Warning: APIX series display is limited to a height of 20 display tiles and the display surface has to obtain the flatness within a tolerance zone of ± 0.2 mm and keep perpendicular to the reference surface.

Setup Process

1. Assemble five APIX series tiles, connect all truss bars, keep them on the same level. Assemble the first line of cabinets. Screw down side lock by hand one by one. All jobs is easy operated.





Image 4-2 Five APIX series tiles installed in the horizontal line



Buckle

Push fast lock
upside



Push buckle

Screw down




Image 4-3 Tiles vertically connected with side lock



Warning: APIX series side fast locks were chosen the same devices with bottom fast locks, when combine horizontally, please kindly follow the same method to assemble as above.

APIX series

Assemble APIX series tiles line by line , install from middle to side, and from top to bottom .keep all truss bars on the same level.




Image 4-4 Five APIX series tiles installed line by line

APIX series

3. Install all the tiles for a whole screen.




Image 4-5 Installed APIX series screen

APIX series

4.3 Setup Process of Standing Installation



Warning: The height of APIX series tiles depends on the height of supporting steel structure and the display surface has to obtain the flatness within a tolerance zone of +/- 0.2mm and keep perpendicular to the reference surface.

Setup Process

1. Assemble five APIX series tiles ,make sure all steel structure were under right design, keep base flat on the same level .assemble the first line of cabinets. Screw down side lock by hand one by one. All jobs is easy operated.




Image 4-6 First line tiles installation



Buckle

Push fast lock upside

Push buckle

Screw down




Image 4-7 Two tiles vertically connected with side lock



Warning: APIX series side fast locks were chosen the same devices with bottom fast locks, when combine horizontally ,please kindly follow the same method to assemble as above.

APIX series

2. Assemble APIX series tiles line by line , install from middle to side, and from bottom to top .keep each line of tiles on the same level.




Image4-8 Installation Instruction

3. Fix the corners of four adjacent tiles with connecting plates and corresponding screws, make sure fixed fasten to steel structure. and make appropriate adjustments if necessary to ensure the smooth and seamless surface of the APIX series display.




Image 4-9 Connecting plates between tiles

APIX series

4. Fix all the corners of the APIX series tiles at the bottom and flanks with connecting plates. Fix the connecting plates to the supporting steel structure at the back of the display. (See the steel structure design and installation image for more details.)




Image 4-10 Example of stacked installation (5 X 5 tiles)

APIX series

4.4 Data and power Cabling

Connect power cable and signal cable as below :for it's design, power cable should be connected line by line, factory original main power cable is 2.5mm²,for safe use ,each cable limited to connected 16 tiles. Signal cable connect from the first tile still to the last one, link all tiles as “Z” or “N”.




Image 4-11 power and data cabling (rear view)




Image 4-12 Controller details



Warning: Please pay attention to the connection from image 4-11, which will be as the reference of the latter software screen connection configuration

5. START-UP OF THE SYSTEM

5.1 Software Installation

Before you run the software, please make sure all connection are ready (From PC to sending card, from sending card to LED screen). Put the LED system installation CD into CD-ROM.

1. Double click  to start LED control software installation.

2. Follow the installation instruction until the installation procedure has finished.

5.2 System Operation

First, power on the control system computer, and switch on the power of LED display. follow the procedures and instructions as below :

1. Start Nova LCT control software

Install “Nova LCT control software”, double click the icon (image 5-1) to open Nova LCT Mars control software, and the computer will enter to the interface as image 5-2. “Local system info” shows the real system connection information. when it shows “Control System: 1”, it means the USB serial port connection is ready for communication between PC and controller . If not it shows “Control System: 0”for the connection is not good with no communication. If there is no image on LED screen (green indicator of sending card not flicking), please check DVI cable from graphic card to sending card, then check multi-display mode from control computer. Keep display mode under duplicate mode.



Image 5-1



Image 5-2

APIX series

2. User Login

User login—This menu is for user to login. It is necessary for the configuration of the LED screen. Click “**User**”,--“**Advanced Log-in**”, enter password“**666**”or“**admin**”.




Image 5-3 Login interface

Select “**Config Screen**” directly to follow the next step:




Image 5-4 Configuration interface

3.Go to sending board configuration : As is Shown in image 5-5, select proper resolution for sending card, and it should be close to graphic card. Click “**Save**” to save parameter on HW.

APIX series




Image 5-5 Sending board configuration interface

4. Go to scan board configuration : As is shown in image 5-6, select “**Load File**”, down load “*.rcfg” file from delivered CD. Click “**Send To HW**”, and then the file will be send to each scan board (receiving card). Click “**Save**” and save all files in hardware, when restart power ,files is no need to send again. **If tiles shows correct images before loading file, skip this step and directly jump to step 5.**




Image 5-6 Scan board configuration interface

5. Screen connection

According to the data cabling of your LED Display, fill in the actual value of columns and rows. Choose right ports and fill right scan board size as below. Select correct direction of signal cable cascading. Image 5-7 shows the front view of screen. “S” for the first tile and “E” for the last one. Choose **“Send to HW”** and **“Save”**.




Image 5-7 Screen connection interface

6. TROUBLE SHOOTING

6.1 Software Trouble

Problem type	Problem description	Solution	Reason	Analysis	
Nova LCT	Unable to open NovaLCT	Reinstall "Recover.reg"	Bin files damaged	Virus influenced	
	System notice: NovaLCT.exe-error	Install Microsoft .NET Framework 2.0	Computer is not installed with .NET Framework software	1. Computer is not installed with .NET Framework 2. Already installed, but may be damaged	
	LCT system connection fails	Check the RS-232 connection and communication	The RS-232 communication is not connected or not get through		
		Replace LCT	LCT communication is not stable	Nova LCT version may be changed, confirm that you use the right version.	
	display brightness is not uniform	Set values of R, G, B brightness on the all controllers as the same	Controller's R,G,B brightness values are not the same	1. Brightness values not the same. 2. Data is not saved successfully after setting.	
		The calibration mode of controllers did not set to "On".	The brightness is different before and after calibration	1. Calibration mode is not "On". 2. All the calibration modes are "On", but not successfully saved after setting	
		Change the brightness adjusting mode	Brightness adjusting modes are different between different controllers	1. Brightness adjusting modes are not set as the same 2. The setting is not saved successfully	
		Check Gamma value of different controllers and resend the database	Gamma values are different for different controllers		
		If brightness adjusting is in auto modes and controlled by sensor, new update need to wait for 30 seconds	Brightness sensor action need to wait for 30 seconds.		
		LCT software monitor shows wrong status	Change and re-install LCT software	Software problem	
		One area of receiver card is black	Check the row and column setting in LCT	Map setting in the LCT is wrong	
	Nova Studio	The whole display is black	Close the play time schedule	Time schedule setting is wrong	
			Check the media source	Media source is lost or stopped	

6.2 System Hardware Trouble

Problem type	Problem description	Solution	Reason	Analysis
Controller	Black screen	No DVI signal output from the graphics card in PC	No DVI signal to the controller	
		Check the power of the controller	No power for the controller	
		Re-start the controller		
Divider	Divider driving area is black	Check RUN status on the divider. If it blinks 2 seconds once, it means no data from the fiber cable.	There is no data from the controller or the fiber cable is not well connected	Divider is working when RUN lamp blinks 2 times per second. The lamp blinking 2 seconds per time means no data is output from controller or the fiber is broken
		Check the power of the divider	No power for the divider	
Receiver card	Receiver card problem causes black display on single tile	Check data input from upper receiver card(RUN lamp blinks 2 times per second). If the data in is ok but problem still exists, replace the receiver card	Hardware problem	
		If there is no data input from the cat5, check the cat5 connection or no data output from the upper receiver card	Poor Cat5 connection or output data problem of the upper receiver card	
	One row of the module in the tile is black or messed up	Check the HUB card scan card, or the ribbon cable connection between the hub card and module. If connection is no problem, replace the hub card	Connection problem or hardware problem	

6.3 Module Problems

Problem type	Problem description	Phenomenon & Solution	Reason	Analysis
LED lamp	Blind lamps	Replace the lamp or module	The lamp is dead or soldering is not good	
LED pixel	The pixel area is black or loses color	Replace the lamp or module	The driving IC/resistor is bad soldered or out of work	
LED module	One or several whole LED modules in the same row are black or defective	Check the flat cable and power cable connection on the module	Cable is not connected or not well connected	

6.4 Power Problems

Problem type	Problem description	Phenomenon & Solution	Reason	Analysis
Tile power	The whole tile is black	Check power connection with the tile and the breaker in the tile	Power to the tile is not well or the breaker is turned off	
Power supply	The whole tile is black	Replace the defective power supply	The power supply feeding the receiver card is defective	
Power supply	Several nearby module areas are black	Replace the defective power supply	The power supply feeding the module area is defective	

6.5 Data Transfer Problems

Problem type	Problem description	Phenomenon & Solution	Reason	Analysis
Fiber	The display is black	Check the fiber connection and the data I/O order	The fiber cable is broken or the data I/O order is wrong	
Cat 5	The whole column of the display is black	Check the data connection between the divider and the first scan card	The connection is not good or the cat5 is defective	
Cat 5	One or several tiles in column are black	Check the cat5 connection between the tiles	The connection is not good or the cat5 is defective	
Cat 5	All the display light up but the columns are not in right order	Check and correct the Cat5 connection order in the divider	The connection order is wrong	

7 MAINTENANCE

Routine maintenance

1. Make sure the LED display is well ventilated, dry and running in suitable temperature.
2. Regularly check the internal cables inside the LED display are in stable connection, the power supplies are working well, the ground wires are connected well, and the lightning arrester is running well.
3. Regularly wipe the dust on the surface of the LED tile with a soft cloth, and keep the LED display surface clean to avoid brightness differences between clean and unclean LED tiles.

Cautions for use

1. Before power on the LED display, start your computer first, and then turn on the power of LED display.
2. Before turn off the display system, first turn off the power of LED display, and then turn off the computer.
3. When you are editing video playlist, you had better to keep the LED display closed.
4. When failure appears, first turn off the power of LED display, then contact with service department for technical support.

APIX series

Appendix A: Technical Specification

Item	APIX series			
Pixel pitch (mm)	APIX2	APIX3	APIX4T	APIX6
Scan mode	1/16 scan	1/16 scan	1/13 scan	1/8 scan
Pixel configuration	1R1G1B			
Brightness (nit)	1000	1200	5500	1200
Viewing angle	H:160°; V:160°			H:140°; V:140°
Pixel density (pixel/m²)	112'896	65536	43264	25600
Module (mm)	250X250			
Module resolution (pixel)	84x84	64x64	52x52	40x40
Tile size (mm)	500x500mm			
Tile resolution (pixel)	168x168	128x128	104x104	80x80
Tile type and material	Die-casting aluminum cabinet			
Tile weight (Kg)	8			
Average power consumption (W/m²)	180	240	228	150
Max power consumption (W/m²)	520	720	684	450
Refresh rate(Hz)	1920/2880/3840			
Frame rate(Hz)	60			
Drive IC	16 channel constant current driving IC			
processing	12/14/16			
Voltage (V)	AC 100-240			
Serviceability	Back			
Protection grade	IP40(Indoor)	IP65 (Outdoor)	IP40(Indoor)	
Operation/storage temperature and humidity	Operation temperature: -10℃~+40℃; Operation humidity : 10~90%RH Storage temperature: -40℃~+60℃; Storage humidity : 0~90%RH			
Life span (hrs)	100000			
MTBF (hrs)	≥3000			
Source compatibility	CVBS,YC,YUV,RGB,DVI,SDI,HD-SDI			

APIX series

Appendix B: Tile Dimensions

