

KSXHGB Series configuration

Table of contents

KSXHGB01 with KAPPAX cabinet	2
KSXHGB01 with SIGMAX cabinet	
KSXHGB02 with KAPPAX cabinet	3
KSXHGB02 with SIGMAXcabinet	
KSXHGB0145LR	4

KSXHGB01

KAPPAX26B1X1BF cabinet

Hanging applications

 <p>1. Remove the noted feet</p>	 <p>2. Remove the noted pins</p>
 <p>3. Fly bar ready for hanging applications </p>	

Grounding applications

 <p>1. Move these pins to this position</p>	 <p>3. Fly bar ready for grounding applications </p>
--	--

SIGMAX26B1X1BF, SIGMAX39T1X1BF, SIGMAX39T1X2BF, SIGMAX39T1X1WF, SIGMAX39T1X2WF cabinet

Hanging applications


 <p>1. Remove the noted feet</p>	 <p>2. Fly bar ready for hanging applications </p>
--	---

Grounding applications

 <p>1. Remove the noted feet</p>	 <p>3. Fly bar ready for grounding applications </p>
--	---

KSXHGB02

KAPPAX26B1X1BF cabinet

Hanging applications	
 <p>1. Remove the noted feet</p>	 <p>2. Remove the noted pins</p>
 <p>3. Fly bar ready for hanging applications </p>	

Grounding applications	
 <p>1. Move these pins to these positions</p>	 <p>3. Fly bar ready for grounding applications </p>

SIGMAX26B1X1BF, SIGMAX39T1X1BF, SIGMAX39T1X2BF, SIGMAX39T1X1WF, SIGMAX39T1X2WF cabinet

Hanging applications	
 <p>1. Remove the noted feet</p>	 <p>2. Fly bar ready for hanging applications </p>

Grounding applications	
 <p>1. Remove the noted pins</p>	 <p>3. Fly bar ready for grounding applications </p>

Grounding applications



1. Remove the noted feet



2. Fly bar ready for grounding applications

